## SERVICE TIPS



Continental Girbau • Girbau Industrial • Sports Laundry Systems Onepress • Poseidon Textile Care • LG Commercial • Econo

Reference	Subject	Date
ST-116	Rigid Mount Installation to a Concrete Floor	4/27/2020
Product	Rigid Mount Washing Machines	

Summary	The energy generated when a rigid mount washing machine is in operation is transferred thru the base to the concret floor. Improper installation can lead to excess vibration of the washing machine, damage to the facility, and damage to the washing machine.							
Model Info	REM025, RMG033, RMG040, RMG0	55, RMG070						
Required Materials	Non-shrink grout, anchoring adhesive (equivalent to Red Head A7 adhesive anchor), metal leveling spacers, Grade 5 SAE rated threaded rod							
	The rigid mount washers should be po washer weight and its transmitted load provided by manufacturer.							
Concrete Slab Req.	If these requirements cannot be met, the depth required by washer model. The a under existing floor in a pyramid fashi set on. Allow adequate time for the contractions of the contraction of the contracti	area should be on and pour n	4-6" larger t	han washer di	mensions on al	14 sides. Excav	vate	
	If these requirements cannot be met, the depth required by washer model. The aunder existing floor in a pyramid fashi	area should be on and pour noncrete to prope	4-6" larger t	han washer di	mensions on al	14 sides. Excav	vate	
	If these requirements cannot be met, the depth required by washer model. The aunder existing floor in a pyramid fashi	area should be on and pour noncrete to proper REM025	4-6" larger tew concreteerly cure.	han washer di with minimun	mensions on al n # 6 wire mesh	1 4 sides. Excava in area for was	vate	
	If these requirements cannot be met, the depth required by washer model. The aunder existing floor in a pyramid fashi set on. Allow adequate time for the contraction.  Threaded rod diameter (inches)	REM025	4-6" larger tew concrete early cure.	han washer di with minimun RMG040	mensions on al n # 6 wire mesh	1 4 sides. Excava in area for was RMG070	vate	
	If these requirements cannot be met, the depth required by washer model. The a under existing floor in a pyramid fashi set on. Allow adequate time for the contract of the con	area should be on and pour noncrete to proper REM025	4-6" larger tew concrete erly cure.  RMG033 5/8	han washer di with minimun RMG040	RMG055 5/8	14 sides. Excava in area for was RMG070	vate	
	If these requirements cannot be met, the depth required by washer model. The aunder existing floor in a pyramid fashi set on. Allow adequate time for the continuous transfer of the co	REM025	4-6" larger tew concrete erly cure.  RMG033 5/8	RMG040 5/8	RMG055	RMG070	vate	
	If these requirements cannot be met, the depth required by washer model. The aunder existing floor in a pyramid fashi set on. Allow adequate time for the contract of the cont	REM025  ½  7	4-6" larger tew concrete erly cure.  RMG033 5/8 7	RMG040 5/8 7	RMG055	RMG070  3/4  10  8	vate	

## SERVICE TIPS



Continental Girbau • Girbau Industrial • Sports Laundry Systems Onepress • Poseidon Textile Care • LG Commercial • Econo

1. Mark the anchor bolt locations. The top piece of cardboard on the RMG's has holes punched out into it. Those holes are the template for the anchor bolts (threaded rod).





Fig. 2.4

- 2. Drill the holes in accordance with the above sizing chart. Verify that the anchor is about 2 inches above the top of the concrete.
- 3. Remove the anchors from the holes and fill holes with anchoring adhesive. FOLLOW ALL CHEMICAL ADHESIVE MFG INSTRUCTIONS.
- 4. Place anchors back in the holes. Rotate the anchors about 180 degrees to ensure the anchoring adhesive is properly coating the anchor.
- 5. Set the washer over anchors, raise and level the washer a maximum of ½ inch off the floor using spacers under washer frame at or near anchor bolt. The spacer location is important to keep the frame from being damaged when washer is being secured by tightening the anchor.
- 6. Once washer is setting on spacers and is level, fill the space between machine frame and floor surface with non-shrinking machinery grout the full width and depth of frame members of washer. Make a drain opening in the rear of the base grouting approximately 1" wide to allow any water build-up under the base to drain away.
- 7. After the grout is completely dry and the chemical anchor is cured install fastening hardware. Make sure you use the large washer and tighten the nuts alternately until all anchors are securely tightened. It is recommended not to use a locking C-type washer as they often break apart and the machine vibration may allow parts to separate from the mounting nut. This may cause the washer to vibrate, which could result in damage to unit.

## SERVICE TIPS



Continental Girbau • Girbau Industrial • Sports Laundry Systems Onepress • Poseidon Textile Care • LG Commercial • Econo



Always follow the warnings and procedures in the corresponding equipment instruction manual.

