PRODUCT BULLETIN – PB-137.R2 Front load Washers – Bearing and Bearing Tool Kit Info



Summary

The bearing tool kits are designed to properly remove and install bearings when a bearing job is being performed.

The bearing kit includes all of the seals, bearings, adhesive, and grease that is required to perform a bearing job.

The bearing tool kits that have "Puller tool not included" in their respective notes section do not have the 3-armed mechanical puller tool included in the kits. A puller tool that will work is the SKF TMMA 100H Hydraulic EasyPull Bearing Puller (GNA p/n 10623379). This puller can be purchased online if needed.

Models and Part Numbers

Machine	Bearing Tool Kit Part		
Model	Number	Bearing Kit Part Number	Notes
EH020	Puller tool, EH020/ REM025	Bearing Kit, EH020/EM025	
EH030	439679	Bearing Kit, EH030	Puller tool not included
EH040	439661	Bearing Kit, EH040	Puller tool not included
EH055	180760	Bearing Kit, 55# Softmount	
EH060	649392	Bearing Kit, RMG070/EH060	Puller tool not included
EH070	10162683	Bearing Kit, EH070/EH080	Puller tool not included
EH080	10162683	Bearing Kit, EH070/EH080	Puller tool not included
EH090	405274	Bearing Kit, 90# Softmount	
EH130	180158	Bearing Kit, 130# Softmount	
EH190	182972	Bearing Kit, 255# Softmount	
EH255	182972	Bearing Kit, 255# Softmount	
EM033	439679	Bearing Kit, EM040	Puller tool not included
EM040	439679	Bearing Kit, EM040	Puller tool not included
EM055	439661	Bearing Kit, EM055	Puller tool not included
GS023	Puller tool, EH020/ REM025	Bearing Kit, GS023	Need tool 16518292
GS030	439679	Bearing Kit, EH030	Puller tool not included
GS045	439661	Bearing Kit, EH040	Puller tool not included
GS060	649392	Bearing Kit, RMG070/EH060	Puller tool not included
GS070	649392	Bearing Kit, RMG070/EH060	Puller tool not included
GS080	10162683	Bearing Kit, EH070/EH080	Puller tool not included
H1018	191643	Bearing Kit, 18# Softmount	
H1030	191437	Bearing Kit, 30# Softmount	
H1055	180760	Bearing Kit, 55# Softmount	
H1090	405274	Bearing Kit, 90# Softmount	

PRODUCT BULLETIN – PB-137.R2 Front load Washers – Bearing and Bearing Tool Kit Info



	Bearing Tool Kit Part	2	
Machine Model	Number	Bearing Kit Part Number	Notes
H1130	180158	Bearing Kit, 130# Softmount	
H1255	182972	Bearing Kit, 255# Softmount	
H2018	191643	Bearing Kit, 18# Softmount	
H2030	191437	Bearing Kit, 30# Softmount	
H2055	180760	Bearing Kit, 55# Softmount	
H2090	405274	Bearing Kit, 90# Softmount	
H2130	180158	Bearing Kit, 130# Softmount	
H2255	182972	Bearing Kit, 255# Softmount	
H5020	AURORA BEARING KIT 3	No tool kit	
L1018	171355	Bearing Kit, 18# Hardmount	
L1030	171561	Bearing Kit, 30# Hardmount	
L1040 (Coin)	171637	Bearing Kit, 40/50# Coin Hardmount	
L1040 (OPL)	171637	Bearing Kit, 40/50# OPL Hardmount	
L1050 (Coin)	171637	Bearing Kit, 40/50# Coin Hardmount	
L1050 (OPL)	171637	Bearing Kit, 40/50# OPL Hardmount	
L1075	171694	Bearing Kit, 75# Hardmount	
L1125	275669	Bearing Kit, 125# Hardmount	
MG040	439679	Bearing Kit, EM040	Puller tool not included
MG055	439661	Bearing Kit, EM055	Puller tool not included
REM025	Puller tool, EH020/ REM025	Bearing Kit, EH020/EM025	
RMG033	439679	Bearing Kit, EM040	Puller tool not included
RMG040	439679	Bearing Kit, EM040	Puller tool not included
RMG055	439661	Bearing Kit, EM055	Puller tool not included
RMG070	649392	Bearing Kit, RMG070/EH060	Puller tool not included